






## BENCH ASSEMBLY













\* INCREASE MORTISE DEPTH 2MM TO PREVENT TENON FROM BOTTOMING OUT

drawings by David Radtke



## LEG DETAILS (END VIEW)



## BENCH CUTTING LIST

| KEY | QTY | DESCRIPTION                                   |
|-----|-----|---|
| A   | 2   | 2" x 3" x 27" HARDWOOD STRETCHERS             |
| В   | 2   | 1-1/4" x 1-1/2" x 10-1/2" HARDWOOD INNER RAIL |
| С   | 2   | 1" x 1-3/4" x 16" HARDWOOD OUTER RAILS        |
| D   | 2   | 3/4" x 1-1/2" x 12-1/4" HARDWOOD LEG RAILS    |
| E   | 4   | 1-3/4" x 1-3/4" x 15-1/2" HARDWOOD LEGS*      |

\* TRIM LEGS TO 4-DEGEES AT TOP AND BOTTOM FOR GREATER STABILITY

1/4" LEATHER LACING AVAILABLE FROM THE FOLLOWING ONLINE RETAILERS (BUY 2 36-FT. SPOOLS)

https://www.tandyleather.com (look for Kodiak lace) http://www.stecksstore.com/black-kodiak-lace-1-4-x-36-ft-6-4-mm-x-11-m-by-tandyleather-5076-01/

All tenons are 24mm wide based on the Domino Joiner. If you substitute a different tenon maker with imperial measurements we recommend these substitutions:

6мм x 24мм x 40мм substitute 1/4" x 1" x 1-1/2" 10мм x 24мм x 50мм substitute 3/8" x 1 " x 2"